

WBE 0701 - WBE 0702 WBE 0704

WORKSHOP MANUAL

Rel. 0.0




PRODUCTION YEAR

2018

The manufacturer reserves the right to make all the necessary technical or commercial improvements to its products, so there may be some differences between the series of engines and the contents of this manual. However the basic specifications and different operating procedures will remain the same.

by STIGA - No use of the illustrations or duplication, reproduction or translation, even partial, of the texts in this document may be made without explicit authorization.



IMPORTANT NOTICE: The information contained herein is intended for Service Operations and professionals only, able to competently perform the operations described herein, using the appropriate equipment in order to safeguard se-curity and performance of the machine. The manufacturer is not liable for damages or injuries arising from operations performed by individuals or inadequate facilities.











•	CONIENIS	
INTRO	ODUCTION	6
1. RU	LES AND PROCEDURES FOR SERVICE CENTRES	7
1.1.		
1.2.	. Service repairs after guarantee period	7
1.3.	. Fault notification	
1.4.	. Spare parts request	7
2. GE	ENERAL AND SAFETY REGULATIONS	8
2.1.	. Qualification of operators	8
2.2.	. Safety measures	8
2.3.	· · · · · · · · · · · · · · · · · · ·	
2.4.		
2.5.	,	
2.6.	. Symbols and terms used for safety purposes	9
3. TEC	CHNICAL DATA AND SPECIFICATIONS	
3.1.		
3.2.		
3.3.	•	
3.4.	•	
3.5.		
3.6.		
3.7.		
3.8.	. Identification of engine units	13
4. EN	IGINE TUNING AND TESTING	14
4.1.	. Operating guidelines	14
4.2.	. Engine tuning program	14
4.3.	. Functional test	15
5. TAI	NK AND SUPPLY	16
5.1.	. Emptying and removing the tank	17
5.2.	G	
5.3.	. Checking and cleaning the breather pipe	18
6. ST <i>A</i>	ARTING SYSTEM (> manual starter)	19
6.1.	. Removing the starter assembly	19
6.2.	. Replacing the rope	19
6.3.	. Replacing the hooks	20
	ARTING SYSTEM (➤ electric starter)	
	. Removing the starter motor	
7.2.	. Disassembly and cleaning the starter motor pinion	22



	CONTENTS	
8. INT	AKE SYSTEM	23
8.1.	Maintenance of filtering element (> paper)	23
8.1a.	Maintenance of filtering element (> sponge)	25
9. CAI	RBURATION	26
9.1.	Removing and cleaning the carburettor	
9.2.	Replacing the carburettor	
9.3.	Adjusting minimum speed	
9.4.	Adjusting maximum speed	
9.5.	Adjusting the carburation	
10. G	OVERNOR SYSTEM OF THE CARBURETTOR	30
	Adjusting of accelerator cable	
	Adjusting maximum speed	
	Replacing the lever support	
11 10		22
	NITION	
	Checking the efficiency of the ignition system	
11.2.	Checking the starter micro switch (Version with the electric starter mounted on the ter)	
11.20	a. Replacing the micro switch (\succ version with the electric starter mounted on the grass $lpha$	
	Adjusting the air gap and checking the coil	-
	Replacing the coil	
12 TII	RNING OFF AND STOPPING THE ENGINE	37
	Checking the control cable	
	Checking the ignition off microswitch	
	Checking the brake	
	Replacing the system for turning off and stopping the engine	
	HAUST SYSTEM	
13.1.	Removing and replacing the muffler	40
14. EN	GINE BLOCK - External operations	41
14.1.	Checking the compression	41
14.2.	Adjusting the valve clearance	42
14.3.	Dismantling and cleaning the cylinder head	43
14.4	Overhauling the cylinder head and valves	
14.5.	· · · · · · · · · · · · · · · · · · ·	
14.6.	,	
14.7.	G	
14.8.		
14.9.	Replacing the lower compression ring of the engine shaft (sump side)	48




CONTENTS

15. EN	GINE BLOCK - Overhauling internal parts	49
	Removing the engine (> from the lawnmower)	
15.1a	. Removing the engine (➤ from the tractor)	49
15.2.	Carter opening	50
15.3.	Dismantling and checking the camshaft and counterweight governor	51
15.4.	Dismantling and checking the piston, piston rings, connecting rod and engine shaft	53
16. TRC	OUBLESHOOTING	59






INTRODUCTION



In every manual page the following informations are described:



- A: Motor typ for which the page is valid.
- **B**: Reference to the chapter and the argument with the relative numbering.
- **C**: Presence of previous or following chapters from the present chapter.
- **D**: Issue date or possible audit.
- **E**: Audit number.
- **F**: Page progressive numbering.

Certain symbols are used in the manual, highlighting particularly important information, risks, warnings and prescriptions:



Warns of operations that should be carried out with utmost care to avoid impairing the functionality and safety of the machine.



Warns of operations that should be carried out with utmost care to avoid injury to the operator



NOTE: Refers to specific advice by the manufacturer.



Reference to another procedure or part of the manual.



Recommends that washers and O-rings are checked and replaced if necessary.



Refers to use of special tools.



Shows all the operations requiring different intervention methods depending on the engine version.



NOTE: During the description of procedures, the indications "right", "left", "front", "rear", "upper" and "lower" refer to the engine mounted on the machine seen from the user's perspective.

Please read all the contents of this manual to become familiar with the basics of the engine, which is fundamental for operating in a logical manner without making errors or wasting time.



1. RULES AND PROCEDURES FOR SERVICE CENTRES

1.1. Guarantee validity

The warranty is supplied under the terms, procedures and limits stated in the contract.

1.2. Service repairs after guarantee period

The Service Centre must write a report for each intervention containing the serial number of the engine [[3.1], and summary information about the problems complained of, the intervention made and possible spare parts used.

A copy of these reports must be kept and made available to the manufacturer together with the replaced parts, in case clients should make further complaints.

1.3. Fault notification

The manufacturer should be informed of all faults that recur frequently; this allows it to carefully examine the problem and make corrections on the production line.

Similarly, the manufacturer shall report any faults traced on its engines, indicating the best troubleshooting procedure.

1.4. Spare parts request

When asking for spare parts, you must quote their code by referring to the exploded views corresponding to the year of manufacture reported on the nameplate [3.1].





2. GENERAL AND SAFETY REGULATIONS

recommend you:





IMPORTANT: Before commencing with any intervention, carefully read the information provided in the present manual, in particular the following safety regulations.

2.1. Qualification of operators

All maintenance, disassembly and repairs must be carried out by expert mechanics who are familiar with all the accident prevention and safety regulations after reading through the procedures in this manual.

2.2. Safety measures

All the engines are built in conformity with the European safety regulations in force.

To maintain initial safety levels in the long term, the Service Centre should take proactive measures by making checks whenever possible.

Every time you are asked to service the engine (or the machine on which it is installed), you should:

- · check:
- that the safety devices function correctly;
- that the casings and protection covers have not been removed;
- that the nameplates or specification labels have not been removed or made illegible, (as they form an integral part of the safety devices).
- also:
- restore to proper working order any safety devices which have been manipulated or removed;
- replace ineffective, damaged or missing guards and covers;
- replace illegible labels;
- do not carry out operations or modifications on the machine or on the engine that could affect their performance or lead to an improper or different use from the one for which it has been designed and approved;
- warn the customer that the failure to comply with the above points automatically voids the warranty and the responsibility of the manufacturer.

protect hands with suitable working gloves, especially when working near the cutting unit;

 check that you do not cause accidental petrol leaks or other losses;

regulations that apply to most repair shops, we

disconnect the spark plug cap before servicing;

- do not smoke when working on the tank or when handling petrol;
- do not inhale oil or petrol fumes;
- clean up all traces of spilt petrol immediately;
- test the engine in a well-ventilated environment or where there are adequate exhaust fume extraction systems;
- do not pollute the environment with oil, petrol or other waste and dispose of all waste in accordance with the laws in force;



Exhaust gas contains carbon monoxide, which is highly toxic, odourless and colourless. Avoid inhaling.

 Perform tests on the engine in a well-ventilated environment or in the presence of adequate exhaust gas extraction systems.

2.3. Precautions during servicing

As well as following the usual accident prevention






2. GENERAL AND SAFETY REGULATIONS



2.4. Etichette di sicurezza

On the canopy motor, in a immediately identification position, are some indication or prescription plates for the safety operator.

The plates are as follows:



1 - Fire hazard due to:

- Petrol or oil

Prevent by following the precautions below:

- Do not smoke or ignite a flame in the vicinity of the petrol or oil;
- Turn engine off before adding petrol;
- Do not spill petrol on overheated or electric parts of the engine;
- Handle or store petrol or oil in well-ventilated areas;
- Use non-flammable oil for cleaning engine parts.

- Accumulation of flammable material

Prevent by following the precautions below:

- Remove dry leaves, chips, pieces of paper, dust or other flammable material which has accumulated in or is attached to the engine..

- Electrical cabling

Short circuits can cause fires. Prevent by following the precautions below:

- Always keep the electrical connections of the machine clean and tightly sealed;
- Tighten any loose connectors or cabling clamps. Replace those that are damaged.
- **2 -** Observe the instructions and warnings contained in the present manual and on the safety plates on the engine.

Inappropriate functioning and maintenance can result in serious injury or even death.

3 - Ventilation of closed areas:

In the event that it is necessary to start the engine in a closed environment or if petrol or cleaning oil is being used, open doors and windows to ensureadequate ventilation and, therefore, avoid gas poisoning.

4 - Motor label (see [**3.1**])

2.5. Necessary equipment

All the operations can be carried out with the tools normally used in a good garage.

The symbol used for certain interventions indicates that special tools or equipment are recommended.

2.6. Symbols and terms used for safety purposes

Some paragraphs in this manual are preceded by symbols which indicate the following:



Operations that should be carried out with utmost care to avoid impairing the functionality and safety of the engine and/or machine on which it is installed.




Operations that should be carried out with utmost care to avoid injury to operators.

"WARNING" stresses the risk of injury to oneself and others if instructions and regulations are not observed.








3.1. Identification

Every motor is marked with a serial number on the base and applied on the canopy; this serial number characters and can identify:



The serial number must be reported on every operating sheet in the warranty application and is fundamental for identifying and ordering spare parts.

3.2. Technical data

	WBE 0701	WBE 0702	WBE 0704
Displacement	160 cc	140 cc	196 cc
Bore	65 mm	61 mm	70 mm
Stroke	48 ı	mm	51 mm
Compression ratio when new 8,0:1	Minimum 4 bar		oar
Minimum speed (SLOW)	1800 (±150) r.p.m.		o.m.
Maximum speed (FAST)	2900 (±100) r.p.m.		o.m.
Fuel tank capacity	1,0 litres		
Oil sump capacity	0,55 litres		
Dry weight	11,8	0 kg	12,80 kg

3.3. Adjustments

Distance between spark plug electrodes	0,6 - 0,8 mm
Coil air gap	0,35 - 0,45 mm
Inlet valve clearance	0,10 - 0,15 mm
Exhaust valve clearance	0,15 - 0,20 mm

3.4. Expendable materials

		WBE 0701	WBE 0702	WBE 0704
Petrol		l	aded (g mum 90	,
Engine oil	- da 5 a 35 °C - da -15 a + 35°C		SAE 30 10W30	
Spark plug		RC12YC (Champion) or equivalent		
Starter rope		ø 3,	5x2500	mm

3.5. Use limits


The following table gives the use limits of certain components subject to wear, after which the component must be replaced.

		WBE 0701	WBE 0702	WBE 0704
Compression with de-compressor shut		0,8 Mpa (1300 r.p.m.		
Minimum inlet diameter	valve stem		5,32 mm	
Minimum exho stem diameter	aust valve		5,27 mm	
Minimum inlet v	valve head		0,5 mm	
Minimum exho head rim thickn			0,5 mm	
Valve seat dept	h		1,8 mm	
Minimum val length	Minimum valve spring length			
Maximum gap between ends of cylinder rings		1 mm		
Max. axial gap for compression rings		0,15 mm		
Minimum gudgeon pin dia- meter		12,95	5 mm	17,95 mm
Max. gudgeon seat diameter	pin-piston	13,05	5 mm	18,05 mm
Max.	gudgeon pin side	13,07	⁷ mm	18,07 mm
rod diameter	crank side	26,07	⁷ mm	30,07 mm
Diameter aspira	lion cam	28,05 mm		
Diameter discharge cam		27,72 mm		1
Diameter seat of camshaft		13,95 mm		1
Diam. connecting rod's pin on engine shaft		25,92	2 mm	29,92 mm
Verify the engine shaft extremes			0,10 mm	



3. TECHNICAL DATA AND SPECIFICATIONS

3.6. Tightening torques







3. TECHNICAL DATA AND SPECIFICATIONS

3.7. Table of Tightening torques

Chapter Ref.	Description of screw	Tightening torques
5	Tank fixing screws	8 - 10 Nm
5	Tank fixing nut	8 - 10 Nm
6	Fixing nuts, starter assembly	8 - 10 Nm
6	Starter screw	4 - 6 Nm
7	Starter motor mounting screws	22 - 30 Nm
9	Fixing nuts carburettor and filter	8 - 10 Nm
10	Support screw, governor assembly	8 - 10 Nm
11 - 14	Spark plug tightening torque	16 - 18 Nm
11	Coil fixing screw	8 - 10 Nm
11	Coil fixing stud	8 - 10 Nm
12	Brake support screws	8 - 10 Nm
12	Brake support stud	8 - 10 Nm
13	Muffler fixing nuts	8 - 10 Nm
14	Screws valve cover	8 - 12 Nm
14	Fixing head screws	50 - 55 Nm
14	Attachment bolt flywheel	80 - 90 Nm
14	Screws small plate drop wire	8 - 12 Nm
15	Union screws under carter and sump	8 - 12 Nm
15	Counterweight governor fixing screw	8 - 10 Nm
15	Fixing screws lower connecting rod cap	15 Nm


P.S. For the coupling tourque of all standard screws refer to the single table.





3. TECHNICAL DATA AND SPECIFICATIONS

3.8. Identification of engine units

For ease of reference, this manual has subdivided maintenance operations into different sections, each of which refers to an engine component unit as indicated in the diagrams below.











4. ENGINE TUNING AND TESTING



4.1. Operating guidelines

The engine requires a series of interventions (shown in the table below) in order to ensure minimum basic maintenance.

Operation	First 5 hours	Every 5 hours or daily	Every 25 hours or every season	Every 50 hours or every season	Every 100 hours
Check oil level	-		-	-	-
Change oil *(1)	•	-	-		-
Clean muffler and engine	-		-	-	-
Check air cleaner *(2)	-		-	-	-
Replace air cleaner *(2)	-	-		-	-
Check spark plug	-		-	-	-
Replace spark plug	-	-	-		-

^{*(1)} Replace the oil every 25 hours if the engine is working at full load or at high temperatures.

For the operations that are not difficult for the final user the assistance centre must maintain the motor in perfect efficiency, in accordance with two intervention lines:

- Tuning the engine whenever possible.
- Recommending the client a routine maintenance program at set intervals (e.g. at the end of the season or before a long period of inactivity).

4.2. Engine tuning program

As part of general engine tuning or any intervention on the machine, it is recommended that the Service Centre performs a series of operations aimed at maintaining the engine's efficiency.

Tuning should involve:

- external blowing and cleaning the cylinder head, cylinder and muffler by removing any remains of grass and mud;
- checking the oil level, topping up or replacing parts if necessary;
- inspecting the condition of the starter rope and checking that it functions correctly [6.2];
- emptying and cleaning the fuel tank and checking the breather pipe [5.2];

- inspecting the condition of the spark plug;
 checking the distance between the electrodes
 [11.1];
- tightening the screws [[=== 12.2];
- functional test [[4.3].

Should the checks and adjustments fail to achieve a satisfactory result, refer to chapter [[16] for troubleshooting.

^{*(2)} Clean the air filter more often if the machine is working in dusty areas.



4. ENGINE TUNING AND TESTING

4.3. Functional test

A functional test needs to be carried out at the end of each servicing operation, to check that the operations made are effective. The test must be performed in compliance with the safety regulations regarding the use of the machine on which the engine is installed.

The functional test is carried out as follows:

a. Refuelling and checking the supply system

When you have refuelled the tank with new petrol, check the seal of the tank, the cap and the carburettor pipe.

b. Cold starting test

With the throttle control in "CHOKE", start the engine a few times to check it runs normally.

c. Check the engine rpm

When the engine is hot enough, check the engine speed with the throttle control set to "SLO" and "FAST"; the readings should be equal to the specifications [3.2].

d. Hot start test

With the engine hot and the throttle control set to "SLOW", start the engine a few times to check it runs normally.

If all of these operations have a positive result, the engine can be considered fully serviceable and be returned to the client.





5. TANK AND SUPPLY



IMPORTANT: Carefully read the information below before commencing any intervention.

General Information

The **fuel supply system** comprises the petrol tank connected to the carburettor by a pipe; a mesh filter at the bottom of the tank prevents deposits and impurities from reaching the carburettor.

The versions with a lawn mower mounted fuel tank are supplied with a filter mounted at the bottom of the fuel tank, which prevents impurities and dirt from reaching the carburettor.

The versions with a tractor mounted fuel tank, the fuel tank itself forms an integral part of the machine and is connected to the carburettor via a fuel line. An in-line filter prevents impurities and dirt from reaching the carburettor.

The supply to the carburettor float chamber is caused by gravity and the volume of petrol taken from the tank as the engine runs is compensated by a breather pipe in the cap.

See the relevant section [[16] for advice on resolving problems due to the malfunctioning of the petrol supply system.





WARNING: All interventions on the supply system must be performed in safe conditions, therefore:


- do not smoke;
- work in a ventilated environment away from naked flames or unprotected sources of heat;
- collect any remaining petrol by positioning a suitable container under the engine, avoiding soiling the work bench;
- remove all traces of spilt petrol immediately;
- check you have connected the pipes before pouring petrol back into the tank.



5. TANK AND SUPPLY







5.1. Emptying and removing the tank

- 1 Remove the ring (1) of the petrol pipe (2) from the tank side and drain all the fuel from the tank and the pipe into a suitable container.
- 2 Unscrew the two screws (3) at the side and the nut at the rear (4) and remove the tank (5).
- 3 When fitting, perform the above operations in reverse.




WARNING: Before refilling the tank with new fuel, check that the petrol pipe is intact.


5.2. Cleaning the tank

- 1 Remove the tank [🞏 5.1].
- 2 Remove the clamp (1) from the side of the tank and disconnect the petrol pipe (2).
- 3 Slide out the filter tube (6) and blow compressed air through it so as to remove any deposits inside.
- 4 Keeping the hole (7) in the spigot closed, pour about 100 cc of clean petrol into the tank and shake it vigorously to clean the inside.



5. TANK AND SUPPLY





- 5 Empty the tank and dispose of the petrol used for cleaning in accordance with the laws in force.
- 6 Refit the tank [5.1] tightening the screws (3) and the nut (4) to the torques indicated.



WARNING: Before refilling the tank with new fuel, check that the petrol pipe is intact.

5.3. Checking and cleaning the breather pipe

- 1 Remove the cap (8) and pull out the gasket (9) and the sponge (10).
- 2 Check that:
- the gasket (9) is intact and without cracks or fissures;
- the air passages (11) inside the cap are not clogged;
- the sponge (10) is not crushed or broken.



NOTE: Always replace the entire cap if the gasket or sponge is damaged.

Tightening torques

3 Tank fixing screws4 Tank fixing nut8-10 Nm8-10 Nm






6. STARTING SYSTEM (➤ manual starter)



General information


The **starter assembly** inside the cover consists of a rope wound around a pulley. The movement from the pulley to the flywheel (and the engine shaft) is transmitted by a pair of hooks. The rope is returned and rewound by a spiral spring.

See the relevant section [[16] for advice on resolving problems due to the malfunctioning of the starting system.



6.1. Removing the starter assembly

- 1 To get access to the starter assembly (1), the cover (2) must be removed by unscrewing the three nuts (3).
- 2 Refit the starter assembly (1) by tightening the cover nuts (3) to the torque indicated.




6.2. Replacing the rope

- 1 Remove the starter assembly [6.1].
- 2 Keep hold of the pulley (4) and slowly unwind (clockwise) the entire rope (5) to gradually release the return spring.


If the rope breaks, the spring will be already released and you will only have to unwind the rope.


3 - Undo or cut the knot at the end of the rope (5) and remove the section still attached to the pulley.







6. STARTING SYSTEM (➤ manual starter)









- 4 Insert one end of the rope (5) (Ø 3.5mm length 2500mm), through the guide in the ventilation grille, into the hole in the pulley (4), and fasten it by tying a knot.
- 5 Insert the other end of the rope into the grip (6) and fasten it with a knot.
- 6 Rotate the pulley (4), without winding the rope onto it, through about 6 complete turns anticlockwise in order to load the spring. Carefully release the pulley to allow the rope to rewind itself completely onto the pulley.
- 7 Check that the pulley rotates freely.
- 8 After pulling the entire length of the rope, check that the pulley (4) is able to complete another 2-3 turns before compressing the spring.
- 9 Refit the starter assembly [5 6.1].

6.3. Replacing the hooks

- 1 Remove the starter assembly [6.1].
- 2 Undo the screw (7) clockwise and remove the cover (8), setting aside the spring and washer. Take care that the pulley (4) does not slide out of its housing.



NOTE: The screw (7) has a left-handed thread and therefore should be unscrewed clockwise.

3-Move the return springs (9) gently out of the way, rotate the hooks (10) clockwise and remove them.



NOTE: Always replace the complete set consisting of hooks, return springs, cover and screw, as a unit..

- 4 When fitting, tighten the screw (7) to the torque indicated.
- 5 Refit the starter assembly [6.1].

Tightening torques				
3	Fixing nuts, starter assembly	8-10 Nm		
7	Starter screw	4-6 Nm		
Te	chnical information			
Sto	arter rope dimensions	ø 3,5x2500 mm		





7. STARTING SYSTEM (> electric starter)




General information

The **electric starter** system consists of a motor supplied by a 12 Volt battery (mounted on the machine). The battery is charged by a coil type alternator which receives impulses from the magneto flywheel.

See the relevant section [[16] for advice on resolving problems due to the malfunctioning of the starting system.



3



7.1. Removing the starter motor


- 1 Remove the cover by unscrewing the three nuts.
- 2 Remove the flywheel magneto [F 14.5]

- 3 Disconnect the connector (1) from the wiring.
- 4 Disconnect the live cable (2) and the earth cable (3).

- 5 Remove the screws (4) and remove the motor.
- 6 To assemble repeat the operation in reverse. When attaching the connector (1) the three wires must attached in the proper places.
- 7 Install the flywheel magneto [F 14.5]
- 8 Assemble the cover.



7. STARTING SYSTEM (> electric starter)



- 7.2. Disassembly and cleaning the starter motor pinion
- 1 Remove the cover.
- 2 Remove the flywheel magneto [F 14.5].
- 3 Use a screwdriver to rotate the pinion (1) to check that it spins and moves co-axially and can compress the spring (2).
- 4 In case the full movement is impeded by dirt:
- remove the dirt by using compressed air;
- spray with lubricant and repeatedly move the pinion;
- when the movement becomes smooth clean with compressed air;
- spray again with lubricant.

Avoid using grease or oil as it causes dirt to accumulate.

If the motor becomes noisy it should be replaced [7.1].

5- Remove the pinion assembly by undoing the screws (3) and check the condition of the gears (Replace the pinion assembly if there is any damage).





8. INTAKE SYSTEM



General information


The **intake system** uses an air filter directly connected to the carburettor by means of a manifold which conveys the air/petrol mixture to the inlet valve.

See the relevant section [[for advice on resolving problems due to the malfunctioning of the air intake system.

An inefficient filter can let dust or debris enter the cylinder, causing premature wear to the piston rings and cylinder.

The air filter is found on the left hand side of the engine and can be inspected without having to remove other parts.

The filter assembly is to be removed only to accede the carburettor.




8.1. Maintenance of filtering element (> paper)




WARNING: Never run the engine without air filter. The engine would certainly be damaged.

- 1 Clean the area around the filter cover (1) by blowing it with compressed air.
- 2 Remove the cover (1) by exerting pressure on the two upper tongues (2) and remove the filter element (3).
- 3 Check carefully that the element has no holes or tears, and replace it if it is damaged.










 $\dot{\mathbb{N}}$

WARNING: When the filter element is removed the intake duct should be covered to avoid foreign bodies from entering. (see the figure).




8. INTAKE SYSTEM






4 - Bang the air filter element on a hard surface so as to remove excess dirt, and blow it through with compressed air, outwards from the inside.

Replace the element if it is too dirty.




5 - Refit the element(3) and the cover into their housings, into its housing, paying attention to hook up the clips correctly (2).





8. INTAKE SYSTEM






8.1a. Maintenance of filtering element (➤ sponge)

1 - Remove the cover [3.1] and remove the filter element (1).



WARNING: When the filter element is removed the intake duct should be covered to avoid foreign bodies from entering.

2 -Check carefully that the element has no holes or tears, and replace it if it is damaged





WARNING: The filter element must be kept clean and oil soaked and must be replaced if broken, cut or if it is crumbling.

Do not use compressed air to clean the filter element.

- 3 Wash the filter element with water and detergent and dry with a clean cloth.
- 4 Pour two spoons of clean motor oil onto the element and wring the sponge repeatedly until the oil is evenly spread.
- 5 Remove any excess oil with a clean cloth.



9. CARBURATION


General information


The **carburettor** has a float with a fixed jet and a "CHOKE" control.

See the relevant section [[16] for advice on resolving problems due to carburation.

The carburettor is located on the left-hand side of the engine. For maintenance operations it is necessary to dismantle the air intake filter in the sequence shown below.

Dismantle the engine from the machine following the instructions in section [[15.1].







WARNING! All operations on the tank and supply system must be carried out in safe conditions, so:

- do not smoke;
- always empty the tank if petrol is not strictly necessary for the operation to be carried out;
- work in a ventilated environment away from naked flames or unprotected sources of heat;
- collect petrol in a suitable container with a cap using a funnel and avoid spilling it on the work bench;
- remove all traces of spilt petrol immediately;
- check you have connected the pipes before pouring petrol back into the tank.


9.1. Removing and cleaning the carburettor

- 1 Remove the filter element [8.1].
- 2 Pull off the breather tube (1), unscrew the two nuts(2) holding the filter carrier (3) to the engine and remove it.
- 3 Remove the clamp (4) for the petrol pipe (5) from the side of the carburettor and use a suitable container to collect all the petrol in the tank and the pipe.




9. CARBURATION







4 - Remove the gasket (6) and move the intake butterfly rod to the minimum position.



5 - Using pliers, disconnect the intake butterfly rod (7) and slide the small rod (8) for the relative compensation spring upwards.




6 - Disconnect the wire (**9**) from the choke butterfly lever, remove the carburettor (**10**) for the relative compensation spring upwards.(**11**).





7 - Loosen the central screw (12) fastening the float chamber (13) remove the relative gasket (14) and carefully collect all the petrol left in the float chamber.




9. CARBURATION












- 8 Pull out the pin (15), dismount the float (16) and remove the gasket (17).
- 9 Undo the main jet (18) and pull out the pilot jet (19).
- 10 Check that no impurities or dirt are deposited in the seat of the needle (20) and of the pilot jet. Verify that the rubber tip of the needle is not marked or worn.
- 11 Clean the carburettor (10) the main jet (18) and the pilot jet (19) thoroughly by immersing them in clean petrol (or a detergent) for 24 hours. Dry with compressed air, blowing well through the carburettor holes.
- 12 Mount the carburettor following the previous points 8, 7 and 6 in reverse order, remembering that:
- It is always advisable to replace the washer(17) and the gasket (14) of the float chamber;
- the float (16) must oscillate freely on the pin (15);
- the jet (18) should never be modified or replaced with others even if they seem to have the same specifications;
- the choke (21) must open and close regularly;
- the float chamber drain screw (22) must be facing forwards.
- 13 Remount the tie rods (7), (8) and (9) checking that the governor system moves smoothly without stopping.
- 14- Always replace washers (6) and (11) when re-mounting the carburettor onto the engine.
- 15 Fit the filter and tighten the relative nuts (2) to the torque indicated. Refit the filter element [[8.1].




9. CARBURATION









9.2. Replacing the carburettor

1 - Perform operations 1 - 2 - 3 - 4 - 5 - 6 - 12 - 13 - 14 - 15 indicated in section [9.1] above.

9.3. Adjusting minimum speed

- 1 Check that the throttle cable is adjusted correctly [[10.1].
- 2 Let the engine heat up for a few minutes, then set the throttle control to "**SLOW**".

Check the rotation speed on the speed indicator (23).



NOTE: The engine's minimum speed must be between 1800 (±150) rpm.

3 - Turn the screw (24) until you achieve a stable minimum speed within the above values.

9.4. Adjusting maximum speed



NOTE: This operation is carried out by adjusting the governor system [10.2].

9.5. Adjusting the carburation



NOTE: The carburation is set in the factory and does not normally need changing. In the event of irregular functioning, clean the carburettor as indicated in section [5] 9.1].

Tig	htening torques	
6	Carburettor nuts/filter	8-10 Nm
Te	chnical information	
Mir	nimum speed (SLOW)	1800 (±150)r.p.m.
Sp	ecial equipment	
24	Speed indicator	





10. GOVERNOR SYSTEM OF THE CARBURETTOR




General information

The **carburettor governor system** uses a engine shaft linkage fitted on a support fixed to the left-hand side of the engine, completed by a counterweight device, driven by the camshaft, and thus sensitive to changes in the engine's revolution pattern depending on load.


The force of the counterweights, transferred to the control lever, tends to shut the main carburettor butterfly, in opposition with the spring that would keep it open; the balance between the spring loading and the thrust of the counterweights on the control lever modifies the butterfly opening and adapts the flow of fuel to the engine so that the revolution speed is kept constant with engine load changes.

See the relevant section [[for advice on resolving problems related to the governor system.




10.1. Adjusting of accelerator cable

1 - Loosen the screw (1) of the clamp (2) so that the cable casing (3) is free to move.




2 - Set the throttle control lever (4) to "CHOKE".



3 - Move governor control lever (5) forward as far as possible and, by keeping it in this position, lock the casing (3) full tightening the screw (1) of the clamp (2).




10. GOVERNOR SYSTEM OF THE CARBURETTOR




10.2. Adjusting maximum speed

- 1 Check that the throttle cable is adjusted correctly [10.1].
- 2 Let the engine heat up for a few minutes then set the throttle control to "**FAST**".



3 - Check the rotation speed on the speed indicator (6).



4 - Act on the regulation screw (7) to establish the correct value of the maximum turn system.




During the regulation, verify that the movement of the mobile levels (8) don't damage the contact with level air support (9) (position"CHOKE").



NOTE: The engine's maximum speed must be between 2900 (±100) rpm; if you do not read this value, proceed as follows.





- that the spring (10) is intact and positioned at the attachment point furthest from the fulcrum of the control lever;
- that the wire (11) and the relative spring (12) are intact and not deformed;
- that the moving levers (8) are not bent or deformed and replace the entire support if necessary [[10.3].






10. GOVERNOR SYSTEM OF THE CARBURETTOR







- 6 If the above checks do not show any faults, the phasing of the governor's control lever (13) with respect to the counterweight device must be checked:
- stop the engine and move the accelerator control to "**FAST**";
- slacken off the control lever (14) locknut (13);
- without changing the lever (13) position determined by the spring (12) and tie-engine shaft (11), use a screwdriver to turn pin (15) clockwise to the end of its stroke and then lock the nut (14).

10.3. Replacing the lever support

- 1 Position the choke lever to minimum ("**\$LOW**" position).
- 3 Disconnect the accelerator cable (3) and remove the breather pipe (16) and the spring (10).
- 4 Disconnect the choke butterfly wire (17) and undo the two screws (18) securing the support (19) to the engine.
- 5 Perform the above operations in reverse order when assembling.
- 6 Refit the carburettor [79.1].
- 7 Adjust the maximum speed [[10.2].

Tigh	teni	ing '	torq	ues
------	------	-------	------	-----

Support screw, governor assembly

8-10 Nm

Technical information

Maximum speed (FAST) 2900 (±100) r.p.m.

Special equipment

6 Speed indicator



11. IGNITION


General information


The **ignition system** has a flywheel with an electronic coil which supplies high voltage to the spark plug.

See the relevant section [[for advice on resolving problems related to the ignition.

The coil and magneto flywheel are accessible by removing the cowl.

Dismount the engine from the machine by following the instructions in section [[15.1].





11.1. Checking the efficiency of the ignition system

- 1 Dismount the spark plug (1) and look at the colour on the end of the thread. This can give you a good idea of the carburation:
- black: mixture too greasy due to clogged air filter;
- **nut brown:** regular carburation.

Replace the spark plug (with one of the same or equivalent characteristics) if the electrodes (2) are burnt or if the porcelain is broken or cracked.




FIRE HAZARD:

- do not check the ignition system if the spark plug is not screwed in place;
- always use the specific tool for the spark test.
- 2 Connect the tester (3) to the spark plug cap (4) and to earth on the engine (5). Activate the starter and see in the instrument if the spark jumps.
- 3 If the test has a positive result, clean the electrodes (2) with compressed air and adjust the distance to 0.6-0.8 mm. Remount the spark plug and tighten it to the specified levels.


Unless otherwise required, proceed to verify system components as indicated in section [11.2].








- 11.2. Checking the starter micro switch (Version with the electric starter mounted on the grass cutter)
- 1 Disconnect the two connectors (6).



- 2 Using an Ohmmeter tester, (7) make contact with the prods on terminals of the microswitch (8). the instrument should read:
- 0 = microswitch pressed (lever pulled);
- ∞ = microswitch free (lever released);

Otherwise, the micro switch needs replacing. (8).





- 11.2a. Replacing the micro switch (version with the electric starter mounted on the grass cutter)
- 1 Disconnect the two connectors (6) of the starter motor micro switch (8).
- 2 Remove the two nuts (9) and replace the micro switch (8).

WARNING! The starter motor micro switch should be tested before the machine is delivered to the customer.



11. IGNITION






- 3 Check that the coil earth cable is intact. The black spark plug cable (12) should not have any cracks or signs of deterioration or burns which reduce its efficiency and insulation level.
- 4 Slack off the screw (13) and the stud (14) which secure the coil (11).

At the bottom of the machine to which the engine is fitted, release the safety brake.

Rotate the flywheel (15) so as to bring the magnetic inserts next to the poles of the core of the coil.








NOTE: An accurate inspection of the efficiency of a coil can only be carried out in a laboratory equipped with a oscilloscope.

To make a brief check, proceed as follows:

6 - Disconnect the earth cable faston (10) of the coil (11).















- 7 Perform a spark test as indicated in [[11.1].
- If the spark jumps: the coil functions properly and in the event of malfunction, verify that the cut-off cable (17) is not earthed.
- if the spark does not jump: the coil is faulty and must be replaced [11.3].
- 8 Refit the starter assembly [[6.1].



11.4. Replacing the coil

- 1 Remove the starter assembly [6.1].
- 2 Disconnect the faston of the earth cable (10).
- 3 Undo the screw (13) and the stud (14) and remove the coil (11).
- 4 Mount the new coil and regulate the air gap according to the procedure indicated in points 4 and 5 in section [11.3].
- 5 Connect the faston of the earth cable (10).
- 6 Refit the starter assembly [6.1].

Tightening torques				
1	Spark plug tightening torque	16-18 Nm		
13	Coil fixing screw	8-10 Nm		
14	Coil fixing stud	8-10 Nm		
Technical information				

Type of spark plug RC12YC (Champion)

or equivalent

Distance between electrodes 0,6-0,8 mm
Air gap/flywheel 0,35-0,45 mm

Special equipment

7 Tester for spark test





12. TURNING OFF AND STOPPING THE ENGINE



General information Version with the electric starter mounted on the grass cutter


The **engine is turned off and stopped** by releasing a lever on the lawnmower. The cable acts on a lever which simultaneously activates a microswitch that sends the coil to earth as well as a brake which acts on the flywheel.


The brake must be able to stop the engine within 3 seconds after it is turned off.

In the version with the tractor mounted electric starter, we suggest that the operator consults the manual supplied with the vehicle.

To solve problems in the system for turning off and stopping the engine, see the relevant chapter [[16].

To get access to the system for turning off and stopping the engine, remove the starter assembly and the fan.





12.1. Checking the control cable

- 1 Remove the starter assembly [5 6.1].
- 2 Remove the filter assembly.
- 3 Check that the sheath (1) is not bent, that the wire (2) is securely connected to both the lawnmower lever and the lever (3) on the engine and that the terminal (4) is correctly fastened to the support (5).
- 4 Check that the wire (2) runs freely inside the sheath (1) when you move the lever.
- 5 Check that the end of the wire (2) is slightly loose when you release the lawnmower lever.
- 6 Refit the filter assembly.
- 7 Refit the starter assembly [5 6.1].


12.2. Checking the ignition off microswitch


- 1 Disconnect the faston (6) from the microswitch.
- 2 Using an Ohmmeter tester (7) make contact with the prods on terminals "1-COM" of the microswitch (8) and engine earth connection; The instrument should read:
- ∞ = microswitch pressed (lever pulled);
- **0** = microswitch free (lever released);

Otherwise, replace the system for turning off and stopping the engine.



12. TURNING OFF AND STOPPING THE ENGINE





12.3. Checking the brake


- 1 Remove the starter assembly [6.1].
- 2 Check that the thickness of the friction pad (9) is not less than 2 mm at its thinnest point.
- 3 Make sure that the control lever (10) moves freely and remove any remains of grass and mud.
- 4 Refit the starter assembly [6.1].
- 5 Start the engine, release the lawnmower lever and check that the engine stops within 3 seconds.
- 6 If it stops after 3 seconds, replace the entire assembly [[12.4], because the spring or the friction pad are not capable of ensuring compliance with braking times.




WARNING! Never return the lawnmower to your client without checking brake efficiency.



12. TURNING OFF AND STOPPING THE ENGINE





12.4. Replacing the system for turning off and stopping the engine

- 1 Remove the starter assembly [6.1].
- 2 Remove the filter assembly.
- 3 Disconnect the brake wire (2) from the lever (3).
- 4 Disconnect the faston (6) from the microswitch (11).
- 5-Undo the two screws (12) and the stud (13) which secure the support bracket (14).
- 6 When fitting, perform the above operations in reverse, tightening the screws (12) and the stud (13) to the torque indicated.
- 7 Refit the starter assembly [56.1] and the filter assembly.
- 8 Start the engine, release the lawnmower lever and check that the engine stops within 3 seconds.

Tightening torques

12	Brake support screws	8-10 Nm
13	Brake support stud	8-10 Nm

Special equipment

7 Universal tester






13. EXHAUST SYSTEM



The **exhaust system** consists of a muffler installed on the cylinder together with a gasket, a spacer and a heatproof baffle.


In the version with the tractor mounted exhaust system, we suggest that the operator consults the manual supplied with the vehicle.

To solve problems in the exhaust system, see the relevant chapter [[16].



13.1. Removing and replacing the muffler

1 - Remove the two nuts (1) that fix the guard (2) and the muffler.



- 2 Take out the muffler (3) and the heatproof baffle (4).
- 3 On assembly:
- thoroughly clean the cylinder contact surface, removing all deposits or fragments on the heatproof baffle;
- always replace damaged mufflers;
- always replace the heatproof baffle (4) if it is broken or cracked;
- tighten the two nuts (1) to the specified levels.


Tightening torques


1 Muffler nuts

8-10 Nm



14. ENGINE BLOCK - External operations





14.1. Checking the compression

- 1 Remove the cap (1) and take out the spark plug (2).
- 2 Manually set the piston to the TDC (Top Dead Centre) of the compression stroke so that both valves are closed.
- 3 Screw the terminal of the compression testing tool (3) into the spark plug hole and connect the supply pipe to a compressed air socket with a pressure of approximately 4 bar (58 psi).
- 4-On opening the air tap (4), the manometer gauge on the engine side should position itself in the green zone and remain there for about 30 seconds. If the gauge falls rapidly it means that the compression is poor





NOTE: Lack of compression could be due to:


- incorrect valve clearance [[14.2];
- cylinder head loose or cylinder head gasket worn [[14.3].
- lack of seal in the valves [[14.4];
- piston rings worn [[14.3].
- 5 Refit the spark plug (2) and close it to the indicated couple.




14. ENGINE BLOCK - External operations









14.2. Adjusting the valve clearance



WARNING: The adjustment must be made with the engine is cold.


- 1 Remove the cover and demount the spark plug.
- 2 Remove lid (5) which is secured with four screws (6) and remove the washer (7).
- 3 Manually set the piston to the TDC (Top Dead Centre) of the compression stroke so that both valves are closed.
- 4 Use a feeler gauge (8) to check the gap between the rocker arm and the tip of the valve stem; the gauge should pass between without forcing and without a further gap.
- 5 The gap is adjusted by slackening off the nut (9) and suitably adjusting the register nut (10) to obtain the following values:


Inlet - IN = 0,10 - 0,15 Exhaust - EX = 0,15 - 0,20


- 6 Following adjustment, check that the pushrods (11) are properly inserted in the rocker arm housings
- (12) and always fully tighten the nut (9).
- 7 When reassembling check the condition of the gasket (7) of the cover (5) and replace it if it is damaged. Tighten the screws (6) to the torque indicated.
- 8 Assemble the spark plug.




14. ENGINE BLOCK - External operations









14.3. Dismantling and cleaning the cylinder head


- 1 Remove the cover and demount the spark plug.
- 3 Remove the exhaust muffler [F 13.1].
- 4 Remove the starter assembly [6.1].
- 5 Unscrew the screws (13) and remove the cylinder head (14).
- 6 Remove the gasket (15).
- 7 Clean the cylinder head (14) and cylinder surfaces (16).
- 8 Carefully clean the inside of the combustion chamber and remove possible deposits from the valve seats.
- 9 Turn the flywheel by hand to move the piston and check the internal surface of the cylinder (16).
- 10 When mounting:
- The gasket (15) must always be replaced;
- Remount the cylinder head (14) screwing the four screws (13) without fully tightening, then tighten them to the given torque values, using a cross-over sequence.


Take care that the pushrods are positioned correctly in their housings.


11 - Remount the items removed in the reverse order used in dismantling.




14. ENGINE BLOCK - External operations









14.4 Overhauling the cylinder head and valves



NOTE - These paragraphs describe all the operations for checking and overhauling the cylinder head;

it is left to the operator to assess the advisability of performing all the operations described or only part of them, depending on the type of engine problems encountered.

- 1 Dismount the cylinder head [[14.3].
- 2-Move the rocker arms (17); press down the spring seal cap (18) and move it sideways to remove from the valve stem (19).

IMPORTANT - The inlet and exhaust valves are different from each other and can be identified by the marking «IN» (inlet) and «EX» (exhaust), on the valve head.

- 3 Use an emery cloth to remove all incrustations from the valve head and check the thickness of the rim (A); the valve must be replaced if the margin (A) is less than 0.5 mm (inlet IN) o 0,5 mm (exhaust EX) or if it shows signs of burning.
- 4 Check the diameter of stem (**B**) in several points and replace the valve if it is less than the following, even if only in one point:

5,32 mm (inlet - IN) 5,27 mm (exhaust - EX)



NOTE - The valve seats must be ground by hand, using a special grinding tool with an angle of 45°.

5 - Insert the pin (20) in the cylinder head valve uide and then the grinding tool (21).




NOTE - Grinding must be done taking care to remove as little material as possible.

6 - Use a caliper gauge to check the depth of the valve seat (C), which must be 1.8 mm; the cylinder head must be replaced if a greater value is measured.




14. ENGINE BLOCK - External operations







7 - Apply abrasive paste for grinding around the rim of the valve head (19) and then insert the valve into its seat.




- 8 Use the special manually operated tool (22) to grind the seat and rim of the valve.
- 9 Remove the valve and use clean petrol to carefully clean all traces of paste or metal residues from the valve seat and rim.



10 - Check the free length of the spring (23) and replace the spring of it is less than 28,5 mm.




- carefully clean the valve guides and housings of any foreign body;
- apply a film of oil on the valve stems before inserting them in their respective housings;
- ensure the correct position of the inlet valve and the exhaust valve, marked, respectively, with ((IN)) and ((EX)) on the valve head.
- 12 Remount the cylinder head [[14.3] and fix the screws to the indicated couple.
- 13 The valve clearances must be checked whenever the cylinder head is removed and refitted [[14.2].




14. ENGINE BLOCK - External operations






- 14.5. Dismantling and replacing the magneto flywheel
- 1 Remove the starter assembly [6.1].
- 2 Using an airgun, undo the nut (24) and extract the fan (25), setting aside the starter cup (26).
- 3 Undo the screw (28) and the stud (29) and remove the electronic coil (27).




4 - Using a suitable extraction tool, remove the flywheel (30) as indicated in the diagram.

Ensure that the engine shaft key is retained.




- 5 When fitting the flywheel check that the key (31) is in good condition and replace it if it is deformed; fit the starter cup (26) and the fan (25). Close the nut to the indicated couple (24) and utilize a gun.
- 6 Refit the coil (27), tightening the screw (28) and the stud (29) to the torque indicated.
- 7 Readjust the airgap until it is correct [11.2].
- 8 Refit the starter assembly [[6.1].



14. ENGINE BLOCK - External operations






14.6. Alternator removal and replacement (> electric starter version)


1 - Remove the screws and disconnect the connectors from the live cable.

In case of malfunction replace the alternator [[16].




14.7. Checking the oil breather

- 1 Remove the magneto flywheel [14.5].
- 2 Unscrew the two screws (32) fixing the closing plate (33).



- 3 Check that the reed (34) is not blocked or deformed. Replace if this is the case.


 If necessary wash with water and neutral deteraents.
- 4 If necessary, replace the gasket (35) and refit the closure plate (33), tightening the screws to the torque indicated.
- 5 Refit the magneto flywheel [[14.5].





- 14.8. Replacing the upper compression ring of the engine shaft (flywheel side)
- 1 Remove the magneto flywheel [[14.5].
- 2 Take out the spline key (31).
- 3 Use a thin screwdriver inserted under the sealing lip to extract the oil seal ring (37).




14. ENGINE BLOCK - External operations









- 4 The new ring (38) must be inserted with the help of a pipe (39) with a diameter of approximately 50-55 mm, taking care not to damage the sealing lip.
- 5 Refit the key (31) and the magneto flywheel [31].

14.9. Replacing the lower compression ring of the engine shaft (sump side)



NOTE - Before executing this operation discharge all the oil from the bowl and rotate 180° the motor.


- 1 Take out the spline key (40).
- 2 Use a thin screwdriver inserted under the sealing lip to extract the oil seal ring (41).
- 3 Make a paper tube (42) around the shaft to protect the sealing lip and insert the new ring (43) so that it enters its housing.
- 4 Complete the insertion with the help of a pipe (44) of a diameter of approximately 30-35 mm.


Tightening torques			
2	Spark plug tightening torque	16-18 Nm	
6	Valve cover fixing screws	8-12 Nm	
13	Cylinder head screws	50-55 Nm	
24	Flywheel fixing nut	80-90 Nm	
32	Screws small plate louver	8-12 Nm	
Technical information			
Cor	mpression	Min. 4 bar	
Inle	t valve clearance	0,10-0,15 mm	
Exhaust valve clearance 0,15-0,20 mm			
Minimum inlet valve stem diameter 5,32 mm			
Minimum exhaust valve stem diameter 5,27 mm			
Min. inlet valve head rim thickness 0,5 mm			
Min. exhaust valve head rim thickness 0,5 mm			
Valve seat depth 1,8 mm			
Minimum valve spring length 28.5 mm			
Special equipment			


- 3 Compression testing tool
- 21 Valve seat grinding tool
- 22 Valve grinder


15. ENGINE BLOCK - Overhauling internal parts











15.1. Removing the engine (➤ from the lawnmower)

- 1 Empty the tank of fuel [5.1].
- 2 Drain the oil in the sump by removing the filler plug and turning the mower on its side.
- 3 Disconnect the throttle cable (1) and the engine brake cable (2).
- 4 Remove the blade assembly and undo the four screws (3) which are accessible from the bottom of the lawnmower.

Grasp the engine at points which offer a secure grip, taking account of the overall weight given in the relevant table [3.2].

15.1a. Removing the engine (➤ from the tractor)


- 1 Disconnect the accelerator cable (1).
- 2 Disconnect the connector (2) on the electrical wiring, the starter motor power cable (3) and the earth wires (4).
- 3 Remove the four screws which hold the starter motor to the tractor.


Grasp the engine at points which offer a secure grip, taking account of the overall weight of approximately 13 Kg.





15. ENGINE BLOCK - Overhauling internal parts











All the following operations on the grass cutter necessitate the removal of the motor.

15.2. Carter opening

- 1 Position the engine on a stable support and remove the sparkplug.
 Bring the piston to the TDC (Top Dead Centre).
- 2 Turn the engine up-side-down and position it so that the shaft projects upwards.
- 3 Open the crankcase sump by unscrewing the seven screws (6).
- 4 verify the phasing between:
- the engine shaft and the camshaft;


If necessary, re-set the phasing, referring to the indications provided.

- 5 On assembly, follow the steps described in reverse and:
- always replace the gasket (7) between cover and sump;
- ensure that the two centring pins (8) are correctly inserted:
- always replace the compression ring from the sump side [14.8].
- ensure that the governor lever (9) is facing upwards;
- close the screws (6) intersection lock bowl to the indicated couple;
- 6 After installing the engine on the machine:
- refill the sump and make sure that the filler plug is tight.
- check the adjustment of the throttle cable [[10.1] and the brake cable [12.1].
- 7 Following reassembly it is advisable to check the engine's peak rpm [[10.2].




15. ENGINE BLOCK - Overhauling internal parts







- 15.3. Dismantling and checking the camshaft and counterweight governor
- 1 Bring the piston to the TDC (Top Dead Centre).
- 2 Open the crank case [[15.2].
- 3 Remove the camshaft (10).



4 - Measure seat (A) of the camshaft, checking for wear and tear. The value must not be lower than 13,95 mm.



5 - Measure the cams (**B**), checking for wear and tear. The value must not be lower than 28,05 mm (IN) and 27,72 (EX).




6 - Check the regular movement of the pressure reducer (11) and the efficiency of the spring (12); the whole group must always be replaced in the case of breakage or irregular operation of the pressure reducer.




15. ENGINE BLOCK - Overhauling internal parts






7 - Check that the irregolar centrifugal (13) that are not present ruptures of the lubrication pallets.


8-Turn the governor's gears quickly and check that the counterweights (14) expand correctly, causing the pin (15) to be moved axially.



9 - In the case of breakage or irregular operation of the counterweights the whole group, fixed by a plate (16) and a screw (17) must be replaced.




10 - When assembling the new group, care must be taken over the correct positioning of one scraper washer (18) under the sliding pin (19) and the other (20) on the opposite side.




11 - Before fitting the camshaft ensure that the two tappets (21) are correctly housed in their seats.


15. ENGINE BLOCK - Overhauling internal parts








13 - During assembly, refer to the operations in section [[15.2] always remembering to replace the washer (7) between the sump and the housing.



15.4. Dismantling and checking the piston, piston rings, connecting rod and engine shaft




NOTA - These paragraphs describe all the operations for checking and overhauling the thermal components of the engine; it is left to the operator to assess the advisability of performing all the operations described or only part of them, depending on the type of engine problems encountered.




1 - Remove the engine from the machine [🎏 15.1].




- 3 Open the cover [**15.2**].
- 4 Remove the camshaft [15.3].



5- Dismantle the connecting rod (25) cap (24), fixed with two screws (26) (take note of any reference marks for refitting).






- Use the special expanding tool (29) to remove the two compression rings and the oil scraper ring from the piston (27).
- 8 Carefully remove all carbon deposits from the compression rings, the inside of the cylinder and the piston head.



15. ENGINE BLOCK - Overhauling internal parts







9-To check the wear in the compression rings, insert them one at a time into the cylinder (28) by about 10-15 mm and measure the gap between the two ends with a feeler gauge (30); the rings must be replaced if the gap is more than 1 mm.




NOTE - If a gap of more than 0.6 mm is measured with new rings it means that the cylinder is worn beyond the acceptable limits and must be replaced. The cylinder must be replaced if it shows striping due to a seizure.



10 - Use a section of an old ring (31) to carefully clean the inside of the piston (27) ring housings, ensuring that the oil passage holes are not blocked.



11 - To check the wear in the piston ring housings, fit a new ring and measure the residual space with a feeler gauge (32). The piston must be replaced if it is greater than 0.15 mm in the two compression ring housings.




12 - Use a screwdriver to remove the clamping ring (33) and remove the gudgeon pin (34) from the piston (27).




15. ENGINE BLOCK - Overhauling internal parts






13 - Check the diameter of the gudgeon pin (**34**) in several places and replace it if it is less than 12.95 mm, even at a single point.

(> 17,95 mm for the WBE 0704)



14 - Check the diameters of the gudgeon pin housings (A) on the piston (27) and replace the piston if they are more than 13.05 mm, even at a single point.

(> 18,05 mm for the WBE 0704)



15 - Fit the cap (24) to the connecting rod (25) and check the diameter from the gudgeon pin side and the crank side; replace the connecting rod if the values are greater than:


B: 13,07 mm on the gudgeon pin side;

B: (> 18,07 mm for the WBE 0704)

C: 26,07 mm on the crank side.

C: (> 30,07 mm for the WBE 0704)


If the connecting rod is outside measurement tolerances or has small scratches or marks, it is necessary to replace it.








15. ENGINE BLOCK - Overhauling internal parts











16 - Remove the engine shaft (35), checking the diameter of the connecting rod pin with a digital gauge. The value must not be less than 25,92 mm or the engine shaft will have to be replaced.

(➤ 29,92 mm for the WBE 0704)



NOTE - In the case of seizing, the manifolds can be polished with fine emery cloth, only removing foreign matter and checking that the final size remains within the aforementioned limit.

17 - To check the alignment between the manifolds and the protruding part of the shaft, place the engine shaft on two prismatic guides (36) and, with the help of a comparator (37) placed at the end, check the displacement by rotating the shaft. The shaft must be replaced if the displacement exceeds 0.10 mm.



IMPORTANT: A bent shaft must never be repaired!



WARNING - DANGER: A bent shaft causes abnormal vibrations and could be dangerous when the machine is used!

18 - To reassemble the segments on the piston perform sequentially:

- Mount the oil wiper (38), composed of three rings:
- Assemble the rounded edge segment (39) with the rounded edge facing downwards;
- Assemble the live edge segment (40).




NOTE: The two segments (39) and (40) must be oriented with the lights not aligned between them.

19 - Fit the connecting rod (25), gudgeon pin (34) and clamping rings (33) to the piston (27), taking care over the connecting rod marking, which must be pointing towards the engine shaft exit. Piston marking must point towards the exhaust.




15. ENGINE BLOCK - Overhauling internal parts






20 - Put the piston into the ring compression tool (41).




21 - Oil the inside of the piston liberally and insert the piston, with the marking facing the exhaust.



22-Mount the engine shaft (35) and the connecting rod cap (24) with the relative screws (26), taking care with the position references (42) so as to avoid inverting the mounting direction of the cap.


Close the screws (26) to the indicated couple.



23 - After having fixed the connecting rod cap, take the greatest care to ensure that the two position references (22) and (23) punched on the engine shaft and camshaft gears, coincide, ensuring the correct distribution phasing.







- 24 Close the carter and fix the screws (6) to the indicated couple [[15.2].
- 25 Whenever the engine shaft is dismantled and refitted, it is always necessary to:
- replace the sealing ring on the flywheel side [[14.7];
- replace the sealing ring on the sump side [[14.8].

26 - During assembly perform the operations indicated in section [15.2] always remembering to replace the washer (7) between the sump and the housing.

Tightening torques		
6	Union screws under carter and sump	8-12 Nm
17	Counterweight governor fixing	8-10 Nm
	screw Fixing screws lower connecting	15.1
28	rod cap	15 Nm

roa cap		
Technical information		
	WBE 0701 - 0702	WBE 0704
Oil sump capacity	0,55 litri	0,55 litri
Diameter aspiration cam	28,05 mm	28,05 mm
Diameter discharge cam	27,72 mm	27,72 mm
Diameter seat of camshaft	13,95 mm	13,95 mm
Maximum segments gap in the cylinder	1,0 mm	1,0 mm
Max. compression ring axial gap	0,15 mm	0,15 mm
Minimum gudgeon pin diameter	12,95 mm	17,95 mm
Max. gudgeon pin housing diameter on piston	13,05 mm	18,05 mm
Max. connecting rod diameter		
gudgeon pin side	13,07 mm	18,07 mm
crank side	26,07 mm	30,07 mm
Diam. connecting rod's pin on engine shaft	25,92 mm	29,92 mm
Verify the engine shaft extremes	0,10 mm	0,10 mm
Constant a service as a set		

Special equipment

- 31 Piston ring removal expander
- 43 Piston ring compressing tool



16. TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
	The engine brake cable is faulty or unfastened	Adjust and/or replace the cable [12.1]
	The micro switch is faulty	Replace the whole shut-down group [[12.2]
	Coil earth connection	Check electrical cabling of earth wire [[11.2]
	Earth wire is flattened	Replace earth wire [[11.2]
	The coil is faulty and does not supply current or the air gap is too large.	Check coil [[11.2]
	Carburettor dirty	Check and clean the carburettor [9.1]
The engine does not start or starts badly	Poor seal of carburettor needle valve	Clean the carburettor housing and needle valve [
	Choke blocked /not closed	Check and clean the carburettor and the choke [9.1]
	The spark plug is badly connected or faulty	Check spark [🎏 11.1] or replace spark plug
	Blocked air filter	Execute the filter cleaning [🎏 6.1]
	Fouling in the combustion chamber	Dismount the cylinder head and remove fouling [[14.3]
	Insufficient pressure	Check tightness of cylinder head screws, replace washer if necessary. Check wear and tear of the piston rings [[15.4]
Starting is difficult and strains	Oil in the cylinder head	Dismount the cylinder head and clean it [[14.3]
the rope	Pressure reducer fault	Check the pressure reducer and counterweights [15.3]
	The tank cap has a clogged breather pipe	Clean and/or replace the cap [5.3];
	Fouling in the combustion chamber	Dismount the cylinder head and remove fouling [[14.3]
The engine starts but does not run	Insufficient pressure	Check tightness of cylinder head screws, replace washer if necessary. Check wear and tear of the piston rings [[15.4]
	Exhaust is blocked	Check that there is airflow through the exhaust system and replace if necessary [13.1]



16. TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
	The throttle cable is not well adjusted	Check and/or adjust the throttle cable [[10.1]
	The governor malfunctions or there is a problem with the rods	Check the entire governor system [[10]
	Air seepage in the carburettor	Replace the carburettor gaskets [[9.1]
The engine is inefficient or	Carburettor dirty	Check and clean the carburettor [[9.1]
the runs irregularly	Insufficient pressure	Check tightness of cylinder head screws, replace washer if necessary. Check wear and tear of the piston rings [[15.4]
	The coil air gap has been poorly adjusted	Adjust the air gap [[11.2] and if the problem persists, replace the coil [11.3]
	Oxidation or loosening of spark plug connections	Perform spark test [[11.1] or replace spark plug
The engine overreved	Governor blocked due to breakage of centrifugal assembly or breakage of external governor springs. It is possible that the governor is dirty.	Check the entire governor system [[10 and 15]
	Engine screws loose	Tighten the screws
The engine judders	Engine timing faulty	Check wear and tear of the connecting rod of the engine shaft, replace shaft if necessary [[15.4]
The engine does not turn off	The engine brake cable is bent or jammed	Check and/or adjust the cable [[12.1]
The engine does not form on	The earth cable is disconnected or broken	Check earthing connection [[12.2]
The engine does not stop within 3 seconds after it has turned off	Faulty or no clutch lining	Replace the engine stopping system [[12.4]
	Defective breather valve operation	Check and/or replace the breather valve [[14.6]
	Poor piston ring seal	Replace the rings [[15.4]
The engine uses a lot of oil	Excessive gap between the guide and the inlet valve stem	Check and/or replace the valve [[14.4]
	Ring assembly error	Check the assembly of the rings [[15.4]



16. IDENTIFICAZIONE DEGLI INCONVENIENTI

PROBLEM	CAUSE	SOLUTION	
(➤ for the electric starter version)			
	Flat battery	Check and recharge the battery	
	Battery inadequate	Check that the battery corresponds to what is given in the machine specifications.	
Starter motor does not run	Problems with the electric circuit and the devices fitted to the machine	Check all the electrical connections and the efficiency of the control devices fitted to the machine.	
	Electrical insufficiency of the starter motor	Replace the starter motor	
	The starter micro switch is faulty	Replace the micro switch [12.2]	
	Battery insufficiently charged	Check and recharge the battery	
The starter motor turns but cannot start the engine	Mechanical inefficiency of the starter motor	Dismantle the motor and clean the pinion zone [[7.2]	
•	Broken flywheel	Check and/or replace the flywheel [[14.5]	
	No power supply to battery	Check alternator charge [[14.5]	
The engine does not start or	Starting motor short circuit (burnt rotor and stator)	Replace starting motor [7.1]	
starts badly	No earth	Check electrical cabling of earth wire [57.1]	
	The coil is faulty and does not supply current or the air gap is too large.	Check coil [[11.3]	







